

SPECIAL WINTERIZATION INSTRUCTIONS FOR RV/MARINE INSTALLATIONS:

To winterize your ARXL129WSP washer,	To use your washer again,	Optional Winterization Instructions
<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">WINTERIZE</div> <ol style="list-style-type: none"> 1. With washer-dryer power OFF, pour ½ quart of RV-type antifreeze into washer drum; 2. Close door. Advance Cycle Selector to 'B'; 3. Press ON/OFF button, then press START. let the washer-dryer run for 1 to 2 minutes; 4. Press ON/OFF button to turn power OFF. 	<ol style="list-style-type: none"> 1. Reconnect water inlet hoses to corresponding HOT/COLD faucets. Turn faucets ON. <i>NOTE: Check water inlet hoses and pump periodically (see Users Guide);</i> 2. Plug washer-dryer into appropriate electrical outlet (see Users Guide) - OR reconnect power supply; 3. With washer-dryer power OFF, pour 1/2 TBSP. of powder detergent (or liquid equiv.) into compartment '2' inside Dispenser Drawer; 4. Advance Cycle Selector to position '9'; 5. Press ON/OFF button, then press START. 	<p>If you're currently pumping antifreeze through your fresh water system, you can follow these steps to winterize your washer-dryer:</p> <ol style="list-style-type: none"> 1. With machine power OFF, advance Cycle Selector to position '3'; 2. Press ON/OFF button, then press START. Let machine fill until the drum turns (could take up to 1 to 2 minutes); 3. Press ON/OFF button to turn power OFF; 4. Advance Cycle Selector to 'B'; 5. Press ON/OFF button, then press START.
<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">END</div> <ol style="list-style-type: none"> 5. Unplug washer-dryer from electrical outlet (or disconnect power); 6. Turn water supply faucets OFF. Disconnect inlet hoses from faucets; 7. Drain remaining water from the hoses. FINISHED. 	<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">WINTERIZE</div> <ol style="list-style-type: none"> 6. Allow machine to run through the complete cycle to clean out any remaining antifreeze. FINISHED. 	<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Winterization Option</div> <ol style="list-style-type: none"> 7. After letting antifreeze drain completely from drum, press the ON/OFF button to turn power OFF. FINISHED.
<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">END</div>	<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">END</div>	<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">END</div>



www.splendide.com

IMPORTANT! DO NOT DISCARD!
Keep this page with your owners manual for future reference